

Product Guide

User and Maintenance Information

IMPORTANT INFORMATION: Please save this product guide.

CUSTOMER SERVICE:

United States

PO Box 2
Ulster Park, NY 12487
Office hours: 9-5 EST
Phone (800) 777-4244
Fax (800) 336-5948
(845) 572-3468

www.CommunityPlaythings.com
Sales@CommunityPlaythings.com



J206 6" Childshape Chair J208 8" Childshape Chair J210 10" Childshape Chair J212 12" Childshape Chair

Recommended Use

The Childshape Chair encourages healthy posture, giving back support with feet flat on the floor. The chair can be used for mealtimes and regular classroom use. Childshape Chairs stack for convenient storage.

The J413 Dolly moves a stack easily.

⚠ WARNING

- ▲ This product is intended for use by children of immature judgement; therefore supervision is required at all times.
- ▲ Stack chairs facing a wall to discourage climbing.
- ▲ Stack no more than five high to prevent instability.
- ▲ Stack only equal size chairs together.
- ▲ Never place child on stacked chair. Stacking is for storage purpose only.
- ▲ Childshape Chairs have a maximum working load of 100 lbs (45kg).

⚠ CAUTION

- ▲ For indoor use only, this chair is not waterproof.

Assembly

Your chair comes to you completely assembled in one carton containing:

1. One Childshape Chair.
2. This product guide.

If your shipment is incomplete, please call Customer Service.

Cleaning

Wipe the wooden chair with a damp cloth and a mild detergent. Do not use excessive water.

Accessories

- J413 Chair Dolly
- J439 Seat Belt
- J426 Replacement Chair Tips

Maintenance

Periodically inspect for cracks, breaks, loose parts, loose screws, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

Construction

Wooden components are manufactured from solid maple and finished with a clear nontoxic finish. All edges and corners are rounded for safety and ease of cleaning. Optional seat belt is made of sturdy polypropylene webbing and the locking buckle and attachment clips are made of durable plastic. Chair tips are molded from an elastomer.

User Modifications

We are not responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

